

3 x Lf x .8 = # of screws or sq.'s.x 80 = # of screws / 5 screws every 2' of panel / 250 Screws / Bag

<p>RC1- Ridge Cap 101</p>	<p>OC1 Outside Corner 201</p>	<p>OC2 Outside Corner 202</p>	<p>JC1 -J Channel 501</p>
<p>FJ1—F&J Trim 512</p>	<p>LT* - L Trim / Fascia 507</p> <p>LT312 -3.5" LT512 -5.5" LT6 -6" LT714 -7.25" LT712 -7.5" LT914 -9.25" LT11 -11"</p>	<p>RTG - Rat Guard 502</p>	<p>OD1 - Overhead Door 503</p> <p>GF1 - Gambrel Flashing 510</p>
<p>DT*- Door Trim 513</p> <p>DT714 - 7.25" DT914 - 9.25"</p>	<p>ZT1 - Z Trim 508</p>	<p>DC1 - Drip Cap 509</p>	<p>ET1 Eve Trim 301</p> <p>ET2 Eve Trim 302</p>
<p>ET3—Eve Trim 303</p>	<p>TC1—Track Cover Cball 514</p>	<p>TF1 - Transition Flashing 504</p>	<p>GT1 Gable Trim 401</p>
<p>SF1 - Sidewall Flashing 505</p>	<p>EF1 - Endwall Flashing 511</p>	<p>VF1 - Valley Flashing 506</p>	<p>IC1- Inside Coner 203</p>